

ITEM #1144690

5-Tier pipe shelving

MODEL #WSL5IPS

Français p. 8

Español p. 15

ATTACH YOUR RECEIPT HERE


Serial Number _____ Purchase Date _____



Please call for replacement parts or assistance: 1-866-942-5362
Pacific Standard Time: 8:30 am – 4:30 pm PST Monday to Friday
Or visit our web site: www.whalenfurniture.com

PACKAGE CONTENTS

PART	DESCRIPTION	QUANTITY
A	Side Panel Left	1
B	Side Panel Right	1
C	Metal Bar	2
D	Connect Beam	5
E	Panel Shelf	5



HARDWARE CONTENTS (shown actual size)

AA



1/4" x 13mm Bolt

Qty. 24+1 extra

BB



M4x 30mm Screw

Qty. 25+1 extra

CC



1/4" x 10mm Bolt

Qty. 1

DD



1/4" Nut

Qty. 1

EE



Allen Wrench

Qty. 1


FF



Open Wrench

Qty. 1

GG



Tipping Restraint
Hardware
Qty. 1 set

HH



Touch-up Pen

Qty. 1

SAFETY INFORMATION


Please read and understand this entire manual before attempting to assemble or install the product.

1. Please read the Assembly Instructions prior to assembling the unit.
2. To avoid damage, assemble the unit on a sturdy, level and non-abrasive surface.
3. Keep all hardware and parts out of the reach of children.
4. Please wait until all steps are completed before fully tightening bolts.
5. Make sure all bolts and screws are tightly fastened before the unit is used.
6. Check that all bolts, screws are tight at least every 3 months or as needed.

WARNING

THIS UNIT IS INTENDED FOR USE ONLY WITH THE MAXIMUM WEIGHTS INDICATED. USE WITH PRODUCTS HEAVIER THAN THE MAXIMUM WEIGHTS INDICATED MAY RESULT IN INSTABILITY CAUSING POSSIBLE INJURY. DISTRIBUTE WEIGHT EVENLY.

MAXIMUM LOAD: 200 lb (91 kg)
(evenly distributed)



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 30 minutes.

Tools Required for Assembly: Allen wrench (provided)

ASSEMBLY INSTRUCTIONS


1. Attach the Connect Beam (D) to the Side Panel Left (A) and Side Panel Right (B), Using the 1/4"x 13mm Bolt (AA), tighten with Allen Wrench (EE).

Hardware Used



2. Attach the Metal Bar (C) to the Side Panel Left (A) and Side Panel Right (B), Using the 1/4"x 13mm Bolt (AA), 1/4"x 10mm Bolt (CC), 1/4" Nut (DD), tighten with Allen Wrench (EE) and Open Wrench (FF).
NOTE: DO NOT fully tighten all bolts until you finish assembling all parts. Once assembled, go back and fully tighten all bolts. This will make the assembly easier.

Hardware Used



3. Attach the Panel Shelf (E) to the Side Panel Left (A) and Side Panel Right (B) and Connect Beam (D), Using the M4 x 30mm Screw (BB).

Hardware Used



ASSEMBLY INSTRUCTIONS




4. Attach the Panel Shelf (E) to the Side Panel Left (A) and Side Panel Right (B) and Connect Beam (D), Using the M4 x 30mm Screw (BB).

Hardware Used



5. NOTE: The tipping restraint hardware included is for wooden stud wall construction. It must be attached to a wall stud. Depending upon your wall construction, different anchor hardware maybe required. Please contact your local hardware store for assistance. Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit to prevent the unit from tipping, causing any accidents or damage. The tipping restraints are intended only as a deterrent, they are not a substitute for proper adult supervision. The tipping restraints are not earthquake restraints. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.

Hardware Used



CARE AND MAINTENANCE

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Use of furniture polishes is not necessary. Should you choose to use polishes, test first in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Always use coasters under beverage glasses and flowerpots.
- Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- Stains or marks from crayons or ink markers will be difficult to remove.
- In the event that your furniture is stained or otherwise damaged during use, we recommend that you call a professional to repair your furniture.
- Check bolts/nuts periodically and tighten them if necessary.
- Touch-up Pen (HH) has been provided to repair any small nicks or scratches that may occur during assembly or shipping.

LIMITED LIFETIME WARRANTY


This product is warranted to the original purchaser. If there is a failure in this unit due to defects in materials or workmanship, the manufacturer will repair or replace this item at our discretion without charge. Warranty is void if product has been assembled incorrectly, misused, abused by overloading, altered in any way or damaged due to accident. This warranty is not transferable and does not cover chipping, flaking, scratches, rust, dents, or other damages to the surfaces of this product. Responsibility of the manufacturer is limited to repair or replacement of this product. The manufacturer is not responsible for consequential, incidental, or other damages or losses resulting from product failure.

This warranty is in lieu of all other expressed warranties. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 1-866-942-5362, 8:30 am – 4:30 pm, PST, Monday to Friday.

PART	DESCRIPTION	PART #
A	Side Panel Left	*WSL5IPS-1-SPL
B	Side Panel Right	*WSL5IPS-2-SPR
C	Metal Bar	*WSL5IPS-3-MB
D	Connect Beam	*WSL5IPS-4-CB
E	Panel Shelf	*WSL5IPS-5-PS
AA	1/4"x 13mm Bolt	*WSL5IPS-6-1/4B
BB	M4 x 30mm Screw	*WSL5IPS-7-M4S
CC	1/4"x10mm Bolt	*WSL5IPS-8-1/4B
DD	1/4" Nut	*WSL5IPS-9-N
EE	Allen Wrench	*WSL5IPS-10-AW
FF	Open Wrench	*WSL5IPS-11-OW
GG	Tipping Restraint Hardware	*WSL5IPS-12-TRH
HH	Touch-up Pen	*WSL5IPS-13-TP



Date: 2018-07-26 Rev. 0001-A
Factory # HESLTD

Printed in China